

70g双胶纸; 展开尺寸198*120mm; 成型尺寸66*120mm;
双面印刷; 风琴折再对折

折线

GERMAN

1. Produkteinführung

1. Patrone
2. Haupteinheit
3. Luftstromregelventil
4. Bildschirm
5. Taste
6. Type-C-Schnittstelle
7. Fülltopfen

2. Produktspezifikation

Hauptmaterial	PCTG, Aluminiumlegierung	Kapazität	3,0 ml
Abmessungen	118,65*28,85*16,8 mm (JNT)	Maximale Ausgangsleistung	35W
		Akkukapazität	1600 mAh
		Nettogewicht	65g

3. Schnellstartanleitung

1. Entfernen Sie das Mundstück, füllen Sie e-Liquid durch die Einfüllöffnung ein, setzen Sie das Mundstück wieder auf und lassen Sie es 10 Minuten lang stehen.
2. Ziehen Sie die Patrone heraus, entfernen Sie die Isolierfolie an der Unterseite der Patrone und setzen Sie die Patrone in die Hauptkammer ein.
3. Drücken Sie die Taste innerhalb von 2 Sekunden fünfmal hintereinander, um das Gerät einzuschalten, und nehmen Sie einen Zug, um zu dampfen.

4. Befüllung

Vorsichtsmaßnahmen:

- Stecken Sie die Tropfspitze der Flasche vor dem Befüllen in die Einfüllöffnung.
- Nach dem Befüllen den Füllverschluss (oder das Mundstück) sofort wieder anbringen, um ein Auslaufen zu verhindern.
- Wenn der verbleibende e-Liquid-Füllstand in der Patrone unter die "MIN"-Markierung fällt, füllen Sie rechtzeitig nach.
- Lassen Sie eine neu befüllte Patrone vor der ersten Verwendung 10 Minuten lang stehen, um Schäden an der Kartusche durch Betrieb ohne e-Liquid zu vermeiden.

5. Menü aufrufen
Drücken Sie die Taste viermal hintereinander, um das Menü aufzurufen, und klicken Sie dann, um eine Option auszuwählen. Das Gerät wechselt nach 3 Sekunden Inaktivität automatisch zum Startbildschirm zurück.

5.1 Themenwechsel
Rufen Sie das Menü auf, klicken Sie, um die Option THEME auszuwählen; halten Sie die Taste 1 Sekunde lang gedrückt, um das Untermenü THEME aufzurufen; klicken Sie, um einen UI-Stil auszuwählen; und halten Sie die Taste dann 1 Sekunde lang gedrückt, um die Auswahl zu übernehmen.

5.2 Moduswechsel
Rufen Sie das Menü auf, klicken Sie, um den WAVES MODE oder STORM MODE auszuwählen; halten Sie die Taste 1 Sekunde lang gedrückt, um den ausgewählten Ausgabemodus zu bestätigen.

5.3 Benutzerdefinierter Tap-Sensor-Modus
Rufen Sie das Menü auf, klicken Sie, um den TAP SENSOR auszuwählen; halten Sie die Taste 1 Sekunde lang gedrückt, um das Untermenü TAP SENSOR aufzurufen; klicken Sie, um die Funktion auszuwählen; und halten Sie die Taste dann 1 Sekunde lang gedrückt, um die Einstellung zu übernehmen.

5.4 Helligkeit einstellen
Rufen Sie das Menü auf, klicken Sie, um die BRIGHTNESS auszuwählen; halten Sie die Taste 1 Sekunde lang gedrückt, um die Helligkeit anzupassen.

5.5 Zuzähler zurücksetzen
Rufen Sie das Menü auf, klicken Sie, um die Option PUFF auszuwählen; halten Sie die Taste 1 Sekunde lang gedrückt, um den Puff-Zähler auf Null zurückzusetzen.

5.6 Menü verlassen
Rufen Sie das Menü auf, klicken Sie, um die Option EXIT auszuwählen. Halten Sie die Taste 1 Sekunde lang gedrückt, um das Menü zu verlassen.

6. TAP SENSOR-Menü
6.1 Schnelles Umschalten der Benutzeroberfläche
Rufen Sie das Menü auf, wählen Sie THEME, halten Sie die Taste 1 Sekunde lang gedrückt, um die aktuelle Funktion zu aktivieren; und tippen Sie dreimal oder öfter auf das Gerät, um die UI der Benutzeroberfläche zu wechseln.

6.2 Schnelles Umschalten des Modus
Rufen Sie das Menü auf, klicken Sie, um den MODE auszuwählen; halten Sie die Taste 1 Sekunde lang gedrückt, um die aktuelle Funktion zu aktivieren; und tippen Sie dreimal oder öfter auf das Gerät, um den Ausgabemodus zu wechseln.

6.3 Schnelles Umschalten der Helligkeit
Rufen Sie das Menü auf, klicken Sie, um die BRIGHTNESS auszuwählen; halten Sie die Taste 1 Sekunde lang gedrückt, um die aktuelle Funktion zu aktivieren; und tippen Sie dreimal oder öfter auf das Gerät, um die Helligkeitsstufen zu wechseln.

6.4 Schneller Zugriff auf MAIN MENU
a. Drücken Sie die Taste dreimal hintereinander. Die Leistungsanzeige beginnt zu blinken.
b. Verlassen Sie die Taste kurzlang, um die Leistung anzupassen, indem Sie einen Puff nehmen oder nach 3 Sekunden Inaktivität.

7. Schnittstelle zur Leistungsanpassung
Rufen Sie das Menü auf, klicken Sie, um die Option DEACTIVATE auszuwählen; halten Sie die Taste 1 Sekunde lang gedrückt, um den TTP-SENSOR zu deaktivieren.

8. Schutz und Warnung

- Kurzschlussschutz: Wenn ein Kurzschluss auftritt, zeigt der Bildschirm "ATOMIZER SHORT" an, das Gerät beendet die Ausgabe.
- Niederspannungsschutz: Wenn der Akku schwach ist, zeigt der Bildschirm "BATTERY LOW" an, das Gerät beendet die Ausgabe.
- Überzeit-Schutz: Wenn ein einzelner Puff länger als 6 Sekunden dauert, wird auf dem Bildschirm "OVER 6S" angezeigt und das Gerät stellt die Ausgabe ein.
- Warnung bei offenem Stromkreis: Wenn die Kartusche vom Gerät getrennt ist oder keine eingesetzt ist, zeigt der Bildschirm "NO ATOMIZER" an.

Wichtige Hinweise

- Verwenden Sie ein hochwertiges Netzteil (SV2A) und ein USB-Kabel mit Sicherheitszertifizierung zum Laden.
- Wenn Sie dieses Produkt im Flugzeug mitführen, entfernen Sie bitte die Kartusche aus dem Hauptgerät und verpacken Sie sie separat, um ein Auslaufen aufgrund von Druckveränderungen im Flugzeug zu verhindern.
- Vermeiden Sie hohe Temperaturen, entzündliche und explosive Gegenstände, niedrige Temperaturen, Wasser und feuchte Umgebungen während der Nutzung und Lagerung. Bewahren Sie das Gerät während des Transports nicht zusammen mit harten Gegenständen auf, um Schäden am Gerät zu vermeiden. Es wird empfohlen, das Gerät mindestens einmal im Monat aufzuladen, um seine Lebensdauer zu verlängern.
- Verwenden Sie dieses Gerät nicht in einer Umgebung mit starker statischer Elektrizität.

©2026 By SHENZHEN UWELL TECHNOLOGY CO., LTD.
All Rights Reserved.

ENGLISH

1. Product Introduction

1. Cartridge
2. Main unit
3. Airflow adjustment valve
4. Screen
5. Button
6. Type-C interface
7. Filler plug

2. Product Specification

Main material	PCTG, aluminum alloy	Capacity	3.0ml
Dimension	118.65*28.85*16.8 mm (JNT)	Maximum output power	35W
		Cell capacity	1600 mAh
		Net weight	65g

3. Quick Start Guide

1. Remove the mouthpiece, inject e-liquid through the filling port, then put the mouthpiece back on and let it stand for 10 minutes.
2. Pull out the cartridge, remove the insulating film at the bottom of the cartridge, and insert the cartridge into the main unit.
3. Press the button 5 times consecutively within 2 seconds to turn on the device and take a drag to vape.

4. Filling

Precautions:

- Insert the drip tip of the bottle into the filling port before filling.
- After filling, immediately put the filler plug (or mouthpiece) back on to prevent leakage.
- When the remaining e-liquid in the cartridge is below the "MIN" level, please refill in time.
- After filling a new cartridge for the first time, please let it stand for 10 minutes before use to prevent damage to the pod caused by operation without e-liquid.

5. Enter Menu
Press the button four times consecutively to enter the menu, then click to select an option. The device will automatically return to the home screen after 3 seconds of inactivity.

5.1 Theme switching
Enter the menu, click to select a UI style, then press and hold for 1 second to apply it.

5.2 Mode switching
Enter the menu, click to select either WAVES MODE or STORM MODE, press and hold the button for 1 second to confirm the selected output mode.

5.3 Custom Tap Sensor mode
Enter the menu, click to select TAP SENSOR, press and hold the button for 1 second to enter the TAP SENSOR submenu, click to select the function, then press and hold for 1 second to apply it.

5.4 Brightness adjustment
Enter the menu, click to select BRIGHTNESS, press and hold the button for 1 second to adjust brightness levels.

5.5 Puff counter reset
Enter the menu, click to select PUFF, press and hold the button for 1 second to reset the puff counter to zero.

5.6 Exit Menu
Enter the menu, click to select EXIT. Press and hold the button for 1 second to exit the menu.

6. TAP SENSOR Menu
6.1 Quick UI switching
Enter the menu, select THEME, press and hold the button for 1 second to enable the current function, tap the device 3 times or more to switch UI styles.

6.2 Quick mode switching
Enter the menu, click to select MODE, press and hold the button for 1 second to enable the current function, tap the device 3 times or more to switch output modes.

6.3 Quick brightness switching
Enter the menu, click to select BRIGHTNESS, press and hold the button for 1 second to enable the current function, tap the device 3 times or more to switch brightness levels.

6.4 Quick access to MAIN MENU
Enter the menu, click to select MAIN MENU, press and hold the button for 1 second to enable the current function, tap the device 3 times or more to enter the main menu.

6.5 Disabling Tap Sensor
Enter the menu, click to select DISABLE, press and hold the button for 1 triple to disable TAP SENSOR.

7. Power Adjustment Interface
a. Press the button three times consecutively. The wattage display will begin flashing. Short press/long press to adjust the power.
b. Exit the power adjustment interface by taking a puff or after 3 seconds of inactivity.

8. Protection and Warning

- Short circuit protection: When a short circuit occurs, the screen will display "ATOMIZER SHORT", the device will stop outputting.
- Low voltage protection: When the battery is low, the screen will display "BATTERY LOW", and the device will stop outputting.
- Over-time protection: If a single puff exceeds 6 seconds, the screen will display "OVER 6S", and the device will stop outputting.
- Open circuit warning: When the cartridge is disconnected from the device or there is no cartridge, the screen will display "NO ATOMIZER".

Warm Reminder

- Please use a high-quality power adapter (SV2A) and USB cable that has passed safety certification for charging.
- If you carry this product on a plane, please remove the cartridge from the main unit and pack it separately to prevent leakage due to changes in aircraft pressure.
- Avoid high temperature, flammable and explosive articles, low temperature, water, and humid environment during use and storage. Do not store it with hard objects during transportation to prevent damage to the device. It is recommended to charge the device at least once a month to extend its life time.
- Do not use this device in a strong static electricity environment.

WARNING

- This product is only for people who have reached the legal smoking age. It is strictly forbidden to be used by young children, pregnant women, and women during breastfeeding or patients with heart disease, hypertension, diabetes, depression, and asthma. Keep the product out of the reach of children, non-smokers, and animals.
- This product is suitable for various concentrations of e-liquid. If you directly contact e-liquid when using this product, please clean your hands and forearms thoroughly. If your eyes directly contact the e-liquid, please rinse your eyes with clean water and seek medical attention immediately. If you swallow the e-liquid, rinse your mouth and seek medical attention immediately. Please take the liquid container or label with you when you seek medical attention.
- The product may contain nicotine, which is known to be a highly addictive substance.
- Please keep away from flammables and explosives when using or charging to avoid hazards.
- Do not disassemble the product. The company won't be responsible for any product damage or personal injury caused by the improper operation.

This product is in compliance with the following:

- Electromagnetic Compatibility Directive 2014/30/EU
- Restriction of Hazardous Substances Directive 2011/65/EU
- The Tobacco Products Directive (2014/40/EU)

Battery Recycling:
The product's battery should be collected and sent to related recycling center. This product complies with TPD and MHRA. For any questions about TPD and MHRA, please check the ECIID number on the following website: https://cms.mhra.gov.uk/eciig/7f5c5b0%5D=ecig_brand_taxonomy_term_name%3AUWELL%3Apage%3D0

Product Verification
Visit UWELL's official website www.uwell.com to verify under the SUPPORT navigation bar.

Attention:
Please keep your package and the warranty card.

Warranty Parts
Device and atomizer only. Coil and pod are excluded.

Warranty Service Excluded Conditions

- Expiration of warranty period.
- Damage caused by failure to use, maintain and keep the product according to the requirements of the product instructions.
- Damage caused by maintenance service personnel non-authorized by UWELL.
- Damage caused by using inferior accessories of other brands.
- Damage caused by the force majeure.

Warranty Service Guide

- You can ask the shop you purchased your vaping device for the warranty service.
- You can visit www.uwell.com and ask for warranty service under the SUPPORT navigation bar.
- You can contact us through aftersales@myuwell.com if you have any questions.

Please use your phone camera to scan the QR code for further information.

正面

背面

技术要求及规格:

- 材 质: 70g双胶纸
- 表面处理: /
- 要 求: 双面印刷, 风琴折
- 印刷颜色: K
- 完成后外尺寸: 66*120mm
- 未标注尺寸公差: ±0.5mm
- 注意事项: 无少印, 错印, 颜色正确, 字迹清晰; 不能有色差, 啤穿底纸, 溢胶, 套色不准等现象; 需要符合RoHS要求。

优 维 尔	KPN040套装说明书(德英)(YWR0140)			
	日期	2026.03.15	表面处理	/
	名称	说明书	零件编号	R0140-P661
	材质	/	物料编码	2070302065-00-AAA
视角:	单位: MM	比例: 1:1	共1页 第1页	版本
设计:		审核:	批准:	A/0